

MOONBIKE SAFETY COMPONENTS

At MoonBikes, your safety is our priority. Your MoonBike includes the following security features:



When to perform these checks?
Before each use



Need assistance?
Scan QR code for Customer Support Website &
Tutorials www.moonbikes.com



Direct contact?
Email: support@moonbikes.com

EMERGENCY STOP SWITCH (ON/OFF)

allows you to stop the machine at any time. This switch is to be preferentially used when your MoonBike is stationary.

Check to be done :

- ✓ The MoonBike cannot accelerate when the emergency stop switch is OFF



30s

B R A K E

allows you to slow down and stop the machine during your ride

Check to be done :

- ✓ Brake lever is 8 mm minimum from brake grip when fully pressed



Occasionally, the air and brake fluid can mix which could reduce brake lever distance. To repressurize the brake system, place the MoonBike on a flat surface and use the band provided to clamp the brake and it will auto correct after 24h



M A G N E T I C C I R C U I T B R E A K E R

The only function of this component is to prevent the machine from continuing without the rider after a fall. Never use it as an ON/OFF switch or emergency stop. Doing so could cause an accident. Stop using your MoonBike immediately if the device doesn't work correctly

Check to be done :

- ✓ The MoonBike cannot accelerate when the magnetic circuit breaker is not connected to the base

Please always check the security features are functional before each ride. If you are experiencing any mechanical or electrical issues with your MoonBike, including but not limited to the systems listed above, please stop using immediately and contact your nearest MoonBikes authorized service center or contact MoonBikes directly. www.moonbikes.com